


STANDARD INSTALLATION INSTRUCTIONS FOR DOOR CLOSER

Reminder:







Adjust the closing time: adjust the closing time from 90°-0° to 4s-6s, and the user can extend the time appropriately if there are old people or children.

Left hand door installation diagram
Right hand door installation dimensions are the same

Door to 180° installation position dimension




Installation method: Install on the upper door frame of the sliding door side




Warning user:

- (1) do not screw the governor valve out of the main body of the door closer to avoid oil leakage, resulting in unstable operation of the product.
- (2) when closing the door, let the door close freely under the action of the door closer. Do not apply additional force, otherwise the door closer may be damaged.
- (3) please install according to the use scope and size of this manual.




STANDARD INSTALLATION INSTRUCTIONS FOR DOOR CLOSER



Standard installation method: vertical installation at sliding door side






Right hand door installation diagram left hand door installation size is the same

Door to 180° installation position dimension




Reminder:

Adjust the closing time adjust the closing time from 50% to 4s-6s, and the user can extend the time appropriately if there are old people or children



Shut down slowly

Closing fast



Warning user:

- (1) do not screw the governor valve out of the main body of the door closer to avoid oil leakage, resulting in unstable operation of the product.
- (2) when closing the door, let the door close freely under the action of the door closer. Do not apply additional force, otherwise the door closer may be damaged.
- (3) please install according to the use scope and size of this manual.

